


**HP 82973-60001 REV A HP-IL Interface for IBM PC/XT  
Configuration Card**



H  
P  
I  
L

	<b>X</b>	<b>8</b>	<b>7</b>	<b>6</b>	<b>5</b>
	<b>Y</b>	<b>4</b>	<b>3</b>	<b>2</b>	<b>1</b>
VALUE	<b>8</b>	<b>4</b>	<b>2</b>	<b>1</b>	
<b>F</b>	1	1	1	1	1
<b>E</b>	1	1	1	0	0
<b>D</b>	1	1	0	1	1
<b>C</b>	1	1	0	0	0
<b>B</b>	1	0	1	1	1
<b>A</b>	1	0	1	0	0
<b>9</b>	1	0	0	1	1
<b>8</b>	1	0	0	0	0
<b>7</b>	0	1	1	1	1
<b>6</b>	0	1	1	0	0
<b>5</b>	0	1	0	1	1
<b>4</b>	0	1	0	0	0
<b>3</b>	0	0	1	1	1
<b>2</b>	0	0	1	0	0
<b>1</b>	0	0	0	0	1
<b>0</b>	0	0	0	0	0